

myRoom Palladiom FCU Controller Wired Temperature Sensor and Detached Configuration Instructions

This application note instructs how to wire and configure a temperature sensor to the fan coil unit (FCU) controller when using a myRoom system. Also included are instructions on how to set the FCU to Detached mode. Detached mode causes the FCU controller to continue running without the Palladiom thermostat. Note that a wired temperature sensor is required when in Detached mode.

Affected FCU Controller Model Numbers


SMC53-MYRM, SMC55-MYRM, SMC53-HOSP, and SMC55-HOSP

Wired Sensor Installation

The FCU controller must have a wired thermistor connected to run without the thermostat. The FCU controller is compatible with model THTDPG06 by Tasseron Sensors®. Contact Sales@TasseronUSA.com for order inquiries. If this sensor is not available, you may use a thermistor type NTC, 10 kΩ at 25 °C, with an equivalent temperature vs. resistance curve shown below:

Temperature	°C	5	10	15	20	25	30	35
	°F	41	50	59	68	77	86	95
Resistance (kΩ)		22.05	17.96	14.69	12.09	10.00	8.31	6.94

Wire the thermistor to the solid blue wire and either of the black wires of the FCU Controller's 20-point wire harness. If using an older version of the wire harness, there may be two blue wires. If this is the case, still connect to the blue wire closest to the edge of the harness. Keep the remaining unused wires away from conductive surfaces, or isolate them with individual wire nuts.



Wired Sensor and Standalone Configuration

To configure the FCU controller to use the wired temperature sensor and enter Detached mode (if required), please connect the thermostat to the controller for configuration purposes, then remove the thermostat (if required). Configuration is outlined in the **Configuration Instructions Install** (P/N 041563) at www.lutron.com and specific instructions are below:

1. Set the Basic Configuration.
 - a. Follow the instructions for Basic Configuration according to the HVAC system on site. For example, a 4-pipe, relay control for fan and valves is configuration number "01". Remember to power cycle the thermostat if it has been on for 15 minutes. Configuration mode ability times out after 15 minutes from being powered.
2. Set the Advanced configuration for using a wired sensor.
 - a. Follow the instructions to enter Advanced Configuration Mode and set the following parameter values:
 - i. Set Parameter 02 (Temperature sensor) to 00. This will set the controller to use the wired thermistor connected to it.
3. Set the Advanced configuration for Detached Mode (if required)
 - a. Set the following advanced parameter values:
 - i. Set Parameter 01 (Function Type) to 01. This will set the controller to work on its own without the thermostat.
 - ii. Set Parameter 16 (Detached Setpoint) to the setpoint you would like the controller to maintain.
 - iii. Optional: Set any other Detached parameters (17-20).
4. Exit advanced configuration mode by holding the mode button for 3 seconds on the thermostat. The display will flash and return to displaying the temperature.
5. Disconnect the thermostat.

Reconnecting the thermostat and using the thermostat's sensor

When reconnecting the thermostat to run in normal operation, enter advanced configuration mode again and set the following parameters back to their original values:

1. Set Parameter 01 (Function Type) to 00. This will set the controller to accept the setpoint from the thermostat.
2. Set Parameter 02 (Temperature sensor) to 01. This will set the controller to use the thermostat's embedded temperature sensor. The wired sensor may remain connected to the controller. It will not affect normal operation.

Lutron, myRoom, and Palladiom are trademarks or registered trademarks of Lutron Electronics Co., Inc. in the US and/or other countries.

All other product names, logos, and brands are property of their respective owners.

Lutron Contact Numbers

WORLD HEADQUARTERS

USA
Lutron Electronics Co., Inc.
7200 Suter Road
Coopersburg, PA 18036-1299
TEL: +1.610.282.3800
FAX: +1.610.282.1243
support@lutron.com
www.lutron.com/support

**North & South America
Customer Assistance**
USA, Canada, Caribbean:
1.844.LUTRON1 (1.844.588.7661)
Mexico:
+1.888.235.2910
Central/South America:
+1.610.282.6701

UK AND EUROPE

Lutron EA Limited
125 Finsbury Pavement
4th floor, London EC2A 1NQ
United Kingdom
TEL: +44.(0)20.7702.0657
FAX: +44.(0)20.7480.6899
FREEPHONE (UK): 0800.282.107
Technical Support: +44.(0)20.7680.4481
lutronlondon@lutron.com

ASIA

Lutron GL Ltd.
390 Havelock Road
#07-04 King's Centre
Singapore 169662
TEL: +65.6220.4666
FAX: +65.6220.4333
Technical Support: 800.120.4491
lutronsea@lutron.com

Asia Technical Hotlines

Northern China: 10.800.712.1536
Southern China: 10.800.120.1536
Hong Kong: 800.901.849
Indonesia: 001.803.011.3994
Japan: +81.3.5575.8411
Macau: 0800.401
Taiwan: 00.801.137.737
Thailand: 001.800.120.665853
Other Countries: +65.6220.4666