

## Installation Instructions

*Please Read Before Installing*

## Tabletop Keypad Engraved Faceplate

HKT-5KP, -10KP, -15KP, -6LKP  
HKT-5RL, -10RL, -15RL, -6LRL

### Overview


Tabletop Keypad Engraved Faceplates allow replacement of an existing faceplate with a faceplate that has been engraved to identify each button's function. If the Engraved Faceplate was ordered in a metal finish, an appropriate number of black replacement buttons are included with the Engraved Faceplate.

### Important Notes


**Environment:** Ambient operating temperature: 0-40°C, 32-104°F, 0-90% humidity, non-condensing. Indoor use only.

**Faceplates:** Do not paint controls or faceplates.

**Cleaning:** Clean with a soft damp cloth only. Do not use any chemical or abrasive cleaners.




Slim Buttons\*




Raise/Lower Buttons\*

\* Metal faceplates include Black replacement buttons.


HKT-5KP




HKT-5RL




HKT-10KP




HKT-10RL




HKT-15KP




HKT-15RL



HKT-6LKP




HKT-6LRL




## Installation

- 1. Remove Power.** Unplug the DC Adapter and/or remove the batteries from the keypad before you begin.
- 2. Remove Faceplate.** Remove existing faceplate from keypad by pulling upward along either the left or right edge of faceplate (see Faceplate Removal). If you will not be replacing the buttons, skip to step 5.
- 3. Remove Buttons.** Carefully note the positioning of the buttons before proceeding. Remove buttons from keypad by gently prying upward on button web tabs along left edge of each set of buttons (see Button Removal). The large buttons and the raise/lower buttons are separate from the slim buttons.
- 4. Replace buttons.** Line up the holes in the tabs on the new buttons with the posts on the keypad (for example, the slim buttons' tabs should rest on the first and third posts from the top of the column). Place the tabs onto the posts. ***Press firmly on the D-shaped pads to ensure that they are fully seated on the posts.*** See Button Replacement.
- 5. Install Engraved Faceplate.** Install new faceplate by lining up the button holes in the faceplate with the corresponding buttons on the keypad. Press down firmly on the faceplate until it snaps into place. See Faceplate Installation.


## Faceplate Removal




## Button Removal



## Button Replacement



## Faceplate Installation



---

**Notes:**

---

## Technical and Sales Assistance

If you need assistance, call the toll-free **Lutron Technical Support Center**. Please provide exact model number when calling.

(800) 523-9466 (U.S.A., Canada and the Caribbean)

Other countries call:

Tel: (610) 282-3800

Fax: (610) 282-3090

Visit our Web site at [www.lutron.com](http://www.lutron.com)

## LIMITED WARRANTY

Lutron will, at its option, repair or replace any unit that is defective in materials or manufacture within two years after purchase. After the two year period, a pro-rated warranty applies to this product until eight years after the purchase. For warranty service, return unit to place of purchase or mail to Lutron at 7200 Suter Rd., Coopersburg, PA 18036-1299, postage pre-paid. Telephone the Lutron Technical Support Center toll free at 800-523-9466. For more information regarding this warranty contact your Lutron representative.

**THIS WARRANTY IS IN LIEU OF ALL OTHER EXPRESS WARRANTIES, AND THE IMPLIED WARRANTY OF MERCHANTABILITY IS LIMITED TO TWO YEARS FROM PURCHASE. THIS WARRANTY DOES NOT COVER THE COST OF INSTALLATION, REMOVAL OR REINSTALLATION, OR DAMAGE RESULTING FROM MISUSE, ABUSE, OR IMPROPER OR INCORRECT REPAIR, OR DAMAGE FROM IMPROPER WIRING OR INSTALLATION. THIS WARRANTY DOES NOT COVER INCIDENTAL OR CONSEQUENTIAL DAMAGES. LUTRON'S LIABILITY ON ANY CLAIM FOR DAMAGES ARISING OUT OF OR IN CONNECTION WITH THE MANUFACTURE, SALE, INSTALLATION, DELIVERY, OR USE OF THE UNIT SHALL NEVER EXCEED THE PURCHASE PRICE OF THE UNIT.**

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This product may be covered by one or more of the following U.S. patents: 5,248,919; 5,736,965; 5,838,226; 5,905,442; D389,461; D395,037; D422,969; D428,855; D436,579 and corresponding foreign patents. U.S. and foreign patents pending. Lutron and HomeWorks are registered trademarks of Lutron Electronics Co., Inc.

© 2002 Lutron Electronics Co., Inc.