

Installation Instructions for Large Button Master Control Button Kits

Please Leave for Occupant

Large Button Master Control Button Kits

RALK-2W-SD, RALK-5W-RL,
RALK-5W-AO, RALK-PGM

Overview

The RadioRA® Large Button Master Control Button Kits allow the customization of *RadioRA* Large Button Master Controls. Button Kits may be used to change the color and add engraving to clearly identify each button's function.

Read all instructions completely before installation.

Important Notes



Note: Use only Lutron wallplates with these devices. Non-Lutron wallplates will **NOT** sit flush against the wall.


Mounting: Ensure all controls are correctly wired and mounted before installing button kits or wallplates. Ensure controls are free from debris (e.g. plaster, spackling compound) before installing button kits or wallplates.

Wallplates: Lutron Claro® and Satin Colors™ wallplates are recommended for best color match and clean aesthetic appearance. Do not paint button kits or wallplates.


Cleaning: To clean, wipe with a clean damp cloth. **DO NOT** use any chemical cleaning solutions.

2 Button Master Control Programming: To program a 2 Button Master Control, install the Programming Button Kit (RALK-PGM), make the programming changes, and then reinstall the 2 button kit. **Retain the Programming Button Kit to make future changes.**


RALK-2W-SD




RALK-5W-RL



RALK-5W-AO




RALK-PGM




Installation

1. Remove wallplate and wallplate adapter from Master Control (if applicable).
2. Remove currently installed button kit (if applicable). Remove button kit from Master Control by gently prying it from the top. See Button Kit Removal.
3. Snap on the button kit by lining up the two tabs on the bottom of the button kit with the two slots in the Master Control just above the lower Master Control mounting screw. Using your thumbs, press in the bottom, and then snap in the top of the button kit.
4. Attach Lutron Claro® or Satin Colors™ wallplate adapter and wallplate.
 - a. Loosely install Master Control mounting screws.
 - b. Tighten wallplate adapter mounting screws snug.
 - c. Tighten Master Control mounting screws until wallplate adapter is flush to wall (do not over-tighten).
 - d. Snap wallplate onto wallplate adapter, and verify that button kit is not submerged.
 - e. If button kit is submerged, loosen mounting screws appropriately.

Button Kit Removal



Mounting Diagram



Technical and Sales Assistance

If you need assistance, call the toll-free **Lutron Technical Support Center**. Please provide exact model number when calling.
(800) 523-9466 (U.S.A., Canada and the Caribbean)
Other countries call:
Tel: (610) 282-3800
Fax: (610) 282-3090
Visit our Web site at www.lutron.com

LIMITED WARRANTY

Lutron will, at its option, repair or replace any unit that is defective in materials or manufacture within two years after purchase. For warranty service, return unit to place of purchase or mail to Lutron at 7200 Suter Rd., Coopersburg, PA 18036-1299, postage pre-paid. Telephone the Lutron Technical Support Center toll free at 800-523-9466. After the two year period, a pro-rated warranty applies to this product until eight years after the purchase. For more information regarding this warranty contact your Lutron representative.

THIS WARRANTY IS IN LIEU OF ALL OTHER EXPRESS WARRANTIES, AND THE IMPLIED WARRANTY OF MERCHANTABILITY IS LIMITED TO TWO YEARS FROM PURCHASE. THIS WARRANTY DOES NOT COVER THE COST OF INSTALLATION, REMOVAL OR REINSTALLATION, OR DAMAGE RESULTING FROM MISUSE, ABUSE, OR IMPROPER OR INCORRECT REPAIR, OR DAMAGE FROM IMPROPER WIRING OR INSTALLATION. THIS WARRANTY DOES NOT COVER INCIDENTAL OR CONSEQUENTIAL DAMAGES. LUTRON'S LIABILITY ON ANY CLAIM FOR DAMAGES ARISING OUT OF OR IN CONNECTION WITH THE MANUFACTURE, SALE, INSTALLATION, DELIVERY, OR USE OF THE UNIT SHALL NEVER EXCEED THE PURCHASE PRICE OF THE UNIT.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This product may be covered by one or more of the following U.S. patents: 4,835,343; 4,924,349; D422,567; D436,930; D453,742; D456,783; D461,782; D465,460; D465,770; D466,090; D466,091; D466,484; D475,024; D475,025 and corresponding foreign patents. U.S. and foreign patents pending. Lutron, Claro, and RadioRA are registered trademarks and Satin Colors and seeTouch are trademarks of Lutron Electronics Co., Inc.
© 2004 Lutron Electronics Co., Inc.