



Symbol	Model Number	Description	Qty
	RMJS-5R-DV-B	PowPak switching module	1
	LRF2-VCR2B-P-WH	Radio Powr Savr wireless ceiling-mount vacancy sensor	1
	PJ2-2B-GWH-L01	Pico wireless 2-button control	1
	PICO-WBX-ADAPT	Pico wallbox adapter	1

Control Functionality

Occupant Enters:

Lights do not automatically turn on when an occupant enters the space; lights must be turned on manually.

When Occupied:

Manual: Occupant uses wall switch to turn all lights off.

Occupant Exits:

All lights automatically turn off 15 minutes after all occupants exit.

Add a Vive wireless hub to enable simple setup and re-zoning, system monitoring, timeclock functionality, and advanced integration.