



Symbol	Model Number	Description	Qty
	RMJS-8T-DV-B	PowPak dimming module with 0-10V	1
	LRF2-VKLB-P-WH	Radio Powr Savr wireless corner-mount vacancy sensor	1
	PJ2-3BRL-GWH-L01	Pico wireless 3-button with raise/lower control	1
	PICO-WBX-ADAPT	Pico wallbox adapter	1

Control Functionality

Occupant Enters:

Lights do not automatically turn on when an occupant enters the space; lights must be turned on manually. Maximum light level is set to 80%.

When Occupied:

Manual: Occupant uses wall dimmer to set desired light levels for all lights.

Occupant Exits:

All lights automatically turn off 15 minutes after all occupants exit.

Add a Vive wireless hub to enable simple setup and re-zoning, system monitoring, timeclock functionality, and advanced integration.

Code Notes: For break rooms with daylight, include a 0-10V dimming module per zone and a daylight sensor. Want to add a Vive wireless hub for more features? Go to lutron.com/vive for complete compatibility and design details. This solution requires 0-10V enabled ballasts and drivers by others.