



Symbol	Model Number	Description	Qty
	FCJS-010	Wireless Fixture Control with 0-10V	2
	RMJS-20R-DV-B	20A PowPak relay module	1
	FC-SENSOR	PowPak Fixture Sensor	2
	PJ2-3BRL-GWH-L01	Pico wireless 3-button with raise/lower control	1
	PICO-WBX-ADAPT	Pico wallbox adapter	1

Control Functionality

Occupant Enters:

Lights do not automatically turn on when an occupant enters the space; lights must be turned on manually. Maximum light level is set to 80%. Controlled receptacles automatically regain power when occupant enters.

When Occupied:

Automatic: Overhead lights dim/brighten based on daylight availability. There are two perimeter daylight zones. Manual: Occupant uses wall dimmer to set desired light levels for all lights.

Occupant Exits:

All lights automatically turn off 15 minutes after all occupants exit. 50% of all receptacles automatically turn off 15 minutes after all occupants exit.

Add a Vive wireless hub to enable simple setup and re-zoning, system monitoring, timeclock functionality, and advanced integration.

FCJS models are capable of controlling up to 3 ballasts or drivers. Review the "Vive PowPak Fixture Controls" submittal document for more design details. Want to add a Vive wireless hub for more features? Go to lutron.com/vive for complete compatibility and design details.

This solution requires 0-10V enabled ballasts and drivers by others.