

Cleaning of Cellular Shade Fabrics

Regular Cleaning

- Dust with a feather duster.
- Lightly vacuum fabric with a brush type vacuum attachment.

Soil Removal

- Sponge with a mild detergent and warm water solution and blot dry. (Extra care should be used when cleaning blackout fabrics, as the fabrics could become permanently creased.)
- **Do not use strong detergents or spot removers. Dry cleaning is not recommended. Due to the differences in ultrasonic cleaning operators, we do not recommend this method of cleaning.**