



Symbol	Model Number	Description	Qty
	RMJS-5R-DV-B	PowPak switching module	2
	LRF2-OCR2B-P-WH	Radio Powr Savr wireless ceiling-mount occupancy sensor	4
	PJ2-2B-GWH-L01	Pico wireless 2-button control	2
	PICO-WBX-ADAPT	Pico wallbox adapter	2

Control Functionality

Occupant Enters:

Not more than 50% of the lights automatically turn on when an occupant enters the space. The remaining lights must be turned on manually.

When Occupied:

Manual: Occupant uses wall switch separately to turn off general lighting and daylight zone.

Occupant Exits:

All lights automatically turn off 15 minutes after all occupants exit.

Add a Vive wireless hub to enable simple setup and re-zoning, system monitoring, timeclock functionality, and advanced integration.

Code Notes: For non-daylight open offices, all general lighting can be connected to a single switching module.

Want to add a Vive wireless hub for more features? Go to lutron.com/vive for complete compatibility and design details.