


# How to Create Zone Control with a Vive System in 3 Simple Steps

## Step 1

### Choose dimming and/or switching modules

#### Options available:

- Switching, 0-10V, phase dimming, Ecosystem, contact closure




#### Installation:

- To control a group of lights, simply wire one load controller in front of the first fixture in the zone

#### Programming:

- To pair, hold the power button on your load controller for 10 seconds to put it into listening mode
- Then press the off button on the Pico remote or the light bulb button on the occupancy sensor




## Step 2

### Choose the right wireless remotes for your job to add personal control

#### No need to run wire for 0-10V dimming:

- Pico wirelessly pairs in 10 seconds
- Guaranteed 10-year battery life

Pico remotes sold separately



## Step 3 Add wireless sensors to your job with no wire runs

### Simple installation for occupancy or vacancy sensing:

- Same easy, 10-second wireless pairing
- Guaranteed 10-year battery life
- You can add 10 wireless devices to one 0-10V dimming module
- Daylight sensors also available

#### Occupancy/vacancy sensors



#### Daylight sensor




# Occupancy/Vacancy sensors


## Coverage patterns

Key: ■ minor motion  
■ major motion


Wall mount, 180°  
**139.4m<sup>2</sup> (1,500 ft<sup>2</sup>)—minor motion**  
**3278.7m<sup>2</sup> (3,000 ft<sup>2</sup>)—major motion**




Corner mount, 90°  
**1113.8m<sup>2</sup> (1,225 ft<sup>2</sup>)—minor motion**  
**232.2m<sup>2</sup> (2,500 ft<sup>2</sup>)—major motion**



Wireless ceiling mount, 360°  
**Coverage varies by ceiling height**



Hallway, long narrow field of view  
**Coverage varies by hallway's width and length**



## Optional

Add facility management and advanced functionality such as timeclock



For a list of all Vive wireless solution product model numbers please visit [lutron.com/vive](https://lutron.com/vive) or contact your local sales rep.

Technical Support  
[support@lutron.com](mailto:support@lutron.com)  
1.844.LUTRON1 (588.7661)  
includes 24/7 technical support